SLIDING DOOR GUIDE



2. You will hear a strong *click* when you use the handle to open the door. This means the latch is secured in the "**open**" position.



- 1. Make sure the lock is disengaged by turning the knob clockwise (Red Arrow)
 - -To open, pull the handle to the side (Blue Arrow), but note that the handle does not move far. This is normal.
 - **Excessive torque on the handle can cause damage to the mechanism**



- With the latch already secured in the open" position, you only need to "firmly slide the door closed to latch it shut.
 - *Should the door not latch closed, lift the handle again (*just* until you hear the strong *click* sound), then firmly slide the door shut.